



We receive a number of inquiries about how to extend the height of the sides of our solid side trailers. The accompanying photos show one way that can be done.



For the demonstration we used our 5 X 8 SSR trailer.

Wood used: 6 @ 8' and 2 @ 10' X 6" deck boards. 1 @ 10' and 1 @ 8' 2" x 4"s. 1/2" Plywood for spacers.

We used 1/4" carriage bolts and nuts to secure the deck boards to the 2 X 4's and screws to fasten the 2 X 4's and spacers together.



4 "L" brackets were used to fasten the front extension to the sides.

Contact Teske Mfg if you have questions.