



Note: To convert the 5 wire harness on the Teske trailer to a 4 prong replacement plug, combine the brown/green and brown/yellow wires into the slot next to the white ground wire.

PART ID #	
PART NAME	WIRING DIAGRAM
DATE	FALL, 2008
REVISED	
NOTES	